

Off-the-Road Wheel Repair and Maintenance







# OTR wheel repair and maintenance services

Bridgestone Earthmover Tyres (BSEM) offers a complete OTR wheel maintenance service.

We are continually investing in personnel and resources to provide the products and services you need to reduce wheel operating costs and maintain operating safety. OTR wheel maintenance is an important safety issue in the operation of major mining and industrial equipment. Safety standards for maintenance of OTR wheels and tyres are required by legislation and are supported by the Australian Standard AS4457 Earthmoving Machinery – Off the road wheels, rims and tyres – Maintenance and repair, Parts 1 and 2.

OTR wheels and rims suffer severe dynamic loading cycles during operation that can cause metal fatigue. This, in addition to corrosion and abrasion, can lead to general deterioration of the wheel and tyre assembly. As well as reducing operating life, this becomes a serious safety issue, as disintegration of pressurised tyre and rim assemblies during operation or maintenance can result in serious injuries and death.

# Advanced wheel management systems

Recording the operating history of wheels, rims and rim components is vital to enable detection of unsafe wheels and rims. Bridgestone Earthmover Tyres provides expert advice to help our customers create reliable, non-destructive testing regimes that will identify fatigue and other deterioration in wheels and rim components.

A maintenance management system should also include a data collating program that tracks ands reports on the status of wheel and rim testing. Capture and analysis of tyre and rim operational data ensures a sound understanding of the health of your tyre and rim assets.

### Comprehensive testing and repair services

Our testing facilities employ the latest technology to identify flaws in any of the wheel sections before they fail. At our specialist repair facilities, highly trained operators carry out repairs and component replacement based on the combined expertise of Bridgestone Earthmover Tyres and Topy wheels and rims, the world's largest supplier of OTR wheels to original equipment manufacturers and the aftermarket.

This collaboration allows BSEM to provide the bestqualified and most advanced engineering service, repairs, and sub-manufacturing for wheels and rims in Australia.















# www.bridgestone-earthmover.com.au

# NEW SOUTH WALES Sydney

# Head Office

223 Rookwood Road Yagoona NSW 2199 Telephone: (02) 9722 6111 Facsimile: (02) 9722 6199 Email: sales@bsem.com.au

#### **Hunter Valley**

26 Maskey Road Mt Thorley NSW 2330 Telephone: (02) 6574 2800 Facsimile: (02) 6574 2899

#### SOUTH AUSTRALIA Adelaide

21 Kaurna Avenue Edinburgh Parks SA 5111 Telephone: (08) 8283 9400 Facsimile: (08) 8250 1921

## VICTORIA Melbourne

109 William Angliss Drive Laverton North VIC 3026 Telephone: (03) 8369 9400 Facsimile: (03) 9360 9577

#### Morwell

117 Airlie Bank Road Morwell VIC 3840 Telephone: (03) 5134 1936 Facsimile: (03) 5133 8023

#### TASMANIA Somerset

6-7 Reece Court

Somerset TAS 7322 Telephone: (03) 6435 0450 Facsimile: (03) 6435 0330

#### QUEENSLAND Brisbane

325 Orchard Road Richlands QLD 4077 Telephone: (07) 3456 4800 Facsimile: (07) 3456 4899

#### Mt Isa

20 Ryan Road Mt Isa QLD 4825 Telephone: (07) 4743 7200 Facsimile: (07) 4743 6422

#### Mackay

Paget QLD 4740 Telephone: (07) 4963 9200 Facsimile: (07) 4963 9222

127-131 Connors Road

#### **Townsville**

50 Brookhouse Street Stuart QLD 4811 Telephone: (07) 4778 4888 Facsimile: (07) 4778 1933

# NORTHERN TERRITORY

#### **Darwin**

21 Anictomatis Road Berrimah NT 0828 Telephone: (08) 8947 0591 Facsimile: (08) 8947 1483

# **WESTERN AUSTRALIA**

### Perth

461 Dundas Road Forrestfield WA 6058 Telephone: (08) 9352 0300 Facsimile: (08) 9352 8133

#### Kalgoorlie

50 Great Eastern Highway Kalgoorlie WA 6430 Telephone: (08) 9021 6629 Facsimile: (08) 9021 6489

#### **Bunbury**

2 Palmer Crescent Davenport WA 6230 Telephone: (08) 9725 4800 Facsimile: (08) 9725 4729